



## **LEAK DETECTION CHECK-UP—KNOW IF YOUR SENSORS ARE WORKING!**

You have a sensor in your:      tank interstitial space      piping sump(s)      dispenser pan(s)

Total # of sensors: \_\_\_\_\_

To check the status of your sensors:

- Starting at the date/time screen, hit FUNCTION until the screen reads “LIQUID STATUS”
- Hit STEP to view or PRINT to print
- Make sure ALL your sensors are accounted for in the list
- Hit MODE until the screen returns to the date/time screen

**Don't ignore an “L” alarm!**

\*\*\*If you have any questions about your UST system, call the UST Program at (802) 241-3888\*\*\*